TOSHIBA

TOSHIBA POS Terminal

TEC OPOS Installer

LIU OPOS Setup Guide (32/64bit)

FIRST Edition: Mar 29, 2012

TOSHIBA TEC CORPORATION

Revision Record

Rev. No.	Date	Description
V001.000	29 Mar 2012	First Release

Table of Contents

1. Overview....1
1.1 Objectives....1
1.2 TEC OPOS Control Components....1
2. Installation....2
2.1 Starting the installer....2
2.2 Installation environment selection....3
2.3 Installation Path selection....4
2.4 Control selection....4
2.5 Installation section....5
2.6 Finishing Installation....5
3. Silent Installation....6
3.1. Silent Install with Default settings....6
3.2. Silent Install with change settings....6
3.3 Table of error codes....8
4. Default configured value for the OPOS Control....9
5. Uninstallation....9
5.1 Starting the uninstallation....9
6. Restrictions....10

Caution

- **It is prohibited to copy or transfer a part or whole of this manual without the consent.**
- **The content of this manual is subject to change without notice in the future.**

***Microsoft, Windows, Windows 2000, Windows XP, WEPOS , Windows Vista, Windows 7, POSReady 2009 and POSReady 7 are trade marks of Microsoft Corporation in the U.S. and other countries.**
***The official name of Windows is Microsoft Windows Operating System.**

1. Overview

1.1 Objectives

The objective of this specification is to explain the procedure to install TEC OPOS Control for LIU.

TEC OPOS Control installs the following controls.

LIU

LIUST-C10BI
LIUST-C10BICN
LIUSTAx0
WD111

1.2 TEC OPOS Control Components

These 2 components are required for TEC OPOS Control Kits:

- OPOS Control
- Native Driver


The Device Driver is provided to access the unique hardware for TOSHIBA TEC Terminals. Some Controls require the Device Driver to be installed in advance. And the above two components will be installed automatically when the installer is executed.

2. Installation


2.1 Starting the installer

Execute “OPOS_TEC_LIU_Installer.exe”

1. The description about the installer will be displayed in a few seconds after startup




2. Press “Next” button to proceed.



2.2 Installation environment selection

i) Installation will continue to “Setup Type” screen.

ii) Select the setup type and press “Next”.



Execute

Device Control Object
Service Object
TEC Control panel
Test program

Development


Device Control Object
Header file
TEC Control panel
Test program

Development and Execute

Device Control Object
Service Object
TEC Control panel
Test program
Header file


2.3 Installation Path selection

1. Select the installation location by pressing “Browse” button. Then press ”Next” to continue. By default the installation location is C:\OPOS\TEC.




2.4 Control selection

In the following screen, select the OPOS Control to be installed. By default, all control is selected. Press “Next” button to start the installation.




2.5 Installation section



2.6 Finishing Installation

Click “Finish” button to exit installer.




3. Silent Installation

3.1. Silent Install with Default settings

This is the installation using default setting file “OPOSLIUSetup.ini”. In this case, all of the components will be installed.

3.1.1 Starting the Silent Installation




Run the “SilentSetup_LIU_OPOS.bat” in the Kit.

3.2. Silent Install with change settings

This is the installation using customized setting file “OPOSLIUSetup.ini”. In this case, you need to edit the setting file.

3.2.1. Open the setting file for OPOSLIUSetup.ini with text editor



3.2.2 Edit OPOSLIUSetup.ini (Self-explanatory setting file)

```
;*****************************************************
;This is the file for setting silent installation.
;*****************************************************

;-----------------------------------------------------
;Please select Drivers you want to install.
;
;   (Param)   (Mean)
;       301:    Execute
;       302:    Development
;       303:    Development and Execute
;
;-----------------------------------------------------
[SetupType]
Type=303

;-----------------------------------------------------
;Please select Install Drectory.
;-----------------------------------------------------
[InstallDirectory]
Path=C:\OPOS\TEC\

;-----------------------------------------------------
;Please select development you want to install.
;
;   (Param)   (Mean)
;       1:        install the Develop Environment
;       0:        do not install the Develop Environment
;
; NOTE: Includes files will be installed only by change
;                 SetupType include Development
;-----------------------------------------------------
[Develop Environment]
LIU=1

;-----------------------------------------------------
;Please select feature you want to install.
;
;   (Param)   (Mean)
;       1:        install the feature ( include related OCX automatically, depend on feature)
;       0:        do not install the driver
;
; NOTE: Only one of LIUSTA00 or LIUSTA10 can be selected
;       or else it might cause problem for installation
;       DRV_WD111 will installed library module for LIUWD111
;       If LIUWD111 ON, DRV_WD111 will be installed also
;-----------------------------------------------------
[Execute Environment]
LIUWD111=1
LIUSTA10=0
```

```
LIUSTA00=1
LIUSTC10BI=1
LIUSTC10BICN=1
DRV_WD111=1

;-------------------------------------------------------
; This installer does not require reboot
;-------------------------------------------------------
```

3.3 Table of error codes

After installation, installer creates a log file (“setup.log”). Refer to [ResponseResult] →ResultCode to confirm the result of installation.

```
[ResponseResult]
ResultCode=0
```

This is a table of error codes.

Value	Mean
0	Success
-1	General error
-2	Mode is invalid
-3	Cannot find the necessary data. There are any errors in the response file.
-4	Insufficiency of Memory
-5	Cannot find the response file
-6	Cannot write to the response file
-7	Cannot write to the log file
-8	The path of response file is invalid
-9	Data format is invalid
-10	Data format is invalid
-11	Unknown error occurred
-12	Dialog order is wrong
-51	Cannot create the specific folder
-52	Cannot access the specific file or the specific folder
-53	Selected option is invalid

4. Default configured value for the OPOS Control


When OPOS Driver and OPOS Control are installed, the default communication port value are:

Device Class	ST-M30
LIUST_C10BI	COM2
LIUST_C10BICN	COM2
LIUSTAx0	COM4
WD111	COM4

5. Uninstallation


5.1 Starting the uninstallation

1. Open “Control Panel”.
2. Open “Programs and Features” or “Add or Remove Programs” from the control panel respectively in Windows 7 and Windows XP.
3. Select “OPOS for TEC LIU MCR”, then select “Uninstall” from the right click menu for Windows 7, while Windows XP, press the “Remove” button.




6. Restrictions

NOTE1: On Windows 7 (32-bit) and POSReady 7 (32-bit), in order to complete the silent install, user needs to manually accept the Unsigned Driver Installation Dialog Prompt




NOTE2: On newer version of windows (windows 7, POSReady 7), it is required to turn off the User Account Control in order to complete the installation.

1. Go to Control Panel, select View by: Small icons to display all features, then click User Accounts.



2. Click Change User Account Control Settings.



3. Move the slider to 'Never notify' position. Click 'OK'. A system reboot is required in order to make the UAC changes taking effect.

