

TECUSB Driver Install Guide

Table of Contents

Overview	2
Support Device	2
Installation of TECUSB driver	3

Overview

This is a guide for installing TECUSB driver to use TECUSB devices.

Support Device

The followings are the support devices.


- ◆ Toshiba TEC HS-530 USB Scanner
- ◆ Toshiba TEC LS-780 USB Scanner
- ◆ Toshiba TEC TRST-56 USB Printer
- ◆ Toshiba TEC USB POS-Printer
- ◆ Toshiba TEC USB POSKeyboard(IDCR/Keylock)
- ◆ TEC USB EX POS Keyboard
- ◆ Toshiba TEC USB EX POS Keyboard(IDCR/Keylock)
- ◆ Toshiba TEC LS-780-T1T USB LineDisplay
- ◆ Toshiba TEC LIUST-700 USB LineDisplay
- ◆ Toshiba TEC KITLS-780T1T-USB LineDisplay
- ◆ Toshiba TEC KITLS-780T1T-USB Keyboard
- ◆ Toshiba TEC KITLS-780T1T-USB Keyboard(IDCR)
- ◆ Toshiba TEC LS-2200 USB Scanner
- ◆ Toshiba TEC HS-560 USB Scanner
- ◆ Toshiba TEC LS-2200-VS USB Scanner
- ◆ Toshiba TEC TRST-A1x USB POS-Printer
- ◆ Toshiba TEC LS-140 USB Scanner
- ◆ Toshiba TEC TRST-A1x-CN USB POS-Printer
- ◆ Symbol LS-2208 USB Scanner
- ◆ Symbol LS-9208 USB Scanner
- ◆ DENSO GT11B USB Scanner
- ◆ DENSO GT10B Wireless Scanner(BA10-RKU)

Installation of TECUSB driver


Connect USB device by USB and turn on a power supply.
The following dialogue is displayed.



Choose “No, not this time”. Click on the “Next >” button.



Choose “Install from a list or specific location [Advanced]”. Click on the “Next >” button.




Exclude a check box of "Search removable media [floppy, CD-ROM...]".
 Choose check box of "Include this location in the search."
 Click on the "Browse" button. And appoint a folder with the "TecUSBDEx.INF" file.
 Click on the "Next >" button.



The installation of the TECUSB driver is started.



If an above screen is displayed, it is installation completion.
Click on the "Finish" button.



Finally start device manager. And confirm that it is installed as above.